




THE USE OF POLYETHYLENE WRAP FOR CORROSIVE SOILS
TO BE DETERMINED BY ENGINEER



STEP 1



STEP 2



STEP 3

EXERCISE CARE TO PREVENT PENETRATION OF POLYETHYLENE WRAP WITH GRAVEL, ROCKS, ETC.

FIELD INSTALLATION – POLYETHYLENE WRAP

WHERE SPECIFICALLY REQUIRED FOR SOIL APPLICATIONS

STEP 1 – PLACE TUBE OF POLYETHYLENE MATERIAL ON PIPE PRIOR TO LOWERING IT INTO PLACE.

STEP 2 – PULL THE TUBE OVER THE LENGTH OF THE PIPE. TAPE TUBE TO PIPE AT JOINT. FOLD MATERIAL AROUND THE ADJACENT SPIGOT END AND WRAP WITH TAPE TO HOLD THE PLASTIC TUBE IN PLACE.

STEP 3 – OVERLAP FIRST TUBE WITH ADJACENT TUBE AND SECURE WITH PLASTIC ADHESIVE TAPE. THE POLYETHYLENE TUBE MATERIAL COVERING THE PIPE SHALL BE LOOSE. EXCESS MATERIAL SHALL BE NEATLY DRAWN UP AROUND THE PIPE BARREL, FOLDED ON TOP OF PIPE AND TAPED IN PLACE.

EAGLE RIVER WATER & SANITATION DISTRICT	
<p>POLYETHYLENE WRAP</p>	
SCALE: NONE	DATE: 01-01-09
LAST REVISED: 5/29/96	W-17
APPROVED FOR YEAR 2009	